PLAYSTATION 4 PRO APPLICATION GUIDE

TOP & FRONT PANELS

STEP 1:


Remove decal "A" and place on TOP face. Use device edges to line up.

STEP 2:

Remove decal "B", line up both edges where device starts to curve

STEP 3:

Repeat for "C" and "D"




RIGHT PANELS

STEP 1:

Remove decal "H" and align with edge of decal "B"

STEP 2:

Repeat for "I" and "J"




LEFT PANELS

STEP 1:

Remove decal E and place on indicated surface, use edges of device to line up.

STEP 2:

Repeat for "F" and "G"




BACK PANELS

STEP 1:

Place decal K and line up with edge of decal "E"

STEP 2:

Repeat for "L"



PLAYSTATION 4 PRO APPLICATION GUIDE

TOP & FRONT PANELS

STEP 1:


Remove decal "A" and place on TOP face. Use device edges to line up.

STEP 2:

Remove decal "B", line up both edges where device starts to curve

STEP 3:

Repeat for "C" and "D"




RIGHT PANELS

STEP 1:

Remove decal "H" and align with edge of decal "B"

STEP 2:

Repeat for "I" and "J"




LEFT PANELS

STEP 1:

Remove decal E and place on indicated surface, use edges of device to line up.

STEP 2:

Repeat for "F" and "G"



BACK PANELS

STEP 1:

Place decal K and line up with edge of decal "E"

STEP 2:

Repeat for "L"

