## **PLAYSTATION 4 SLIM** APPLICATION GUIDE

**RIGHT PANELS** 

**LEFT PANELS** 

Remove decal "G" and align with edge of

Line up decal "H" on edge of device as shown

STEP 1:

decal "F"

STEP 2:

Remove decal "D", line up to edge of B

Remove decal "E", line up to edge of C

STEP 1:

STEP 2:


# TOP & FRONT PANELS

#### STEP 1:

Remove decal "A" and place on TOP face using device edges to line up.

#### STEP 2:


Remove decal "B", line up both edges where console starts to curve. Repeat step for decal "C"



## **BACK PANELS**

### STEP 1:

Remove decal "F" and align with edge of decal "D"





## **PLAYSTATION 4 SLIM** APPLICATION GUIDE


## **TOP & FRONT PANELS**

#### STEP 1:

Remove decal "A" and place on TOP face using device edges to line up.

#### STEP 2:

Remove decal "B", line up both edges where console starts to curve. Repeat step for decal "C"



## **RIGHT PANELS**

#### STEP 1:

Remove decal "D", line up to edge of B

#### STEP 2:

Remove decal "E", line up to edge of C



## **BACK PANELS**

### STEP 1:

Remove decal "F" and align with edge of decal "D"



#### STEP 1:

Remove decal "G" and align with edge of decal "F"

#### STEP 2:

Line up decal "H" on edge of device as shown

